

1. UPS イベントログ

| No. | メッセージ  | Severity<br>(初期値) | メッセージ                    |
|-----|--|-------------------|--------------------------|
| 0   | Utility power has been restore                       | 6                 | 入力電源復旧                   |
| 1   | Utility power not available                          | 4                 | 入力電源障害                   |
| 2   | The UPS has return from a low battery condition      | 6                 | バッテリー容量復旧                |
| 3   | The UPS batteries are low and will soon be exhausted | 2                 | バッテリーロー                  |
| 4   | The UPS is working fine                              | 6                 | UPS 正常                   |
| 5   | The UPS is not working fine                          | 2                 | UPS 異常                   |
| 6   | The UPS is not on battery power                      | 6                 | 商用運転中                    |
| 7   | The UPS has switched to battery backup power         | 4                 | バッテリー運転中                 |
| 8   | The testing of UPS is completed                      | 6                 | セルフテスト終了                 |
| 9   | The testing is going on UPS                          | 6                 | セルフテスト開始                 |
| 10  | The UPS has enabled bypass                           | 6                 | バイパスモード                  |
| 11  | The UPS is not on bypass                             | 6                 | バイパスモードから復旧              |
| 12  | Communication to the UPS has been lost               | 2                 | UPS との通信をロスト             |
| 13  | Communication with the UPS has been established      | 6                 | UPS との通信確立               |
| 14  | The UPS has been given shutdown command              | 4                 | SNMP/Web カードからの停止コマンド受信  |
| 15  | UPS turn off   | 6                 | UPS 停止                   |
| 16  | UPS has entered sleep mode                           | 6                 | スリープモード(リブート時の電源 Off)    |
| 17  | The UPS woke up from sleep mode                      | 6                 | スリープ状態(リブート時の電源 Off)から復帰 |
| 18  | The UPS is reboot                                    | 6                 | UPS 出力復旧                 |
| 19  | The UPS shutdown process had been cancelled          | 6                 | シャットダウンキャンセル             |
| 20  | The UPS internal temperature return to normal        | 6                 | UPS 温度が復帰                |
| 21  | The UPS temperature is too high                      | 2                 | UPS 温度が動作温度上限設定をオーバ      |
| 22  | The UPS load return from overload                    | 6                 | 接続容量が復帰                  |
| 23  | The UPS is overload                                  | 2                 | 接続容量が接続容量上限設定をオーバ        |

## 2. SNMP/Web カードイベントログ

| No. | メッセ - ジ                               | Severity<br>(初期値) | Description                        |
|-----|---------------------------------------|-------------------|------------------------------------|
| 0   | Cold boot                             | 6                 | 起動(又はリセットボタンからリセット)                |
| 1   | Warm boot                             | 6                 | コンソール又は Web 画面からのリセット              |
| 2   | Network link up                       | 6                 | ネットワーク上の通信正常                       |
| 3   | Network link down                     | 4                 | ネットワーク上の通信異常                       |
| 4   | Restart                               | 6                 | リスタート                              |
| 5   | Parameters reset to default           | 6                 | パラメータ初期化                           |
| 6   | Parameters checksum error             | 4                 | パラメータチェックサムエラー                     |
| 7   | Firmware upgrade                      | 6                 | ファームウェアアップグレード                     |
| 8   | History log cleared                   | 6                 | データログ消去                            |
| 9   | Extent history log cleared            | 6                 | 拡張データログ消去                          |
| 10  | UPS event log cleared                 | 6                 | UPS イベントログ消去                       |
| 11  | Agent event log cleared               | 6                 | SNMP/Web カードイベントログ消去               |
| 12  | History log interval changed          | 6                 | データログ取得間隔変更                        |
| 13  | Extent history log interval changed   | 6                 | 拡張データログ取得間隔変更                      |
| 14  | Send shutdown warning to clients      | 6                 | 警告メッセージをクライアントコンピュータに送信            |
| 15  | Send shutdown request to clients      | 6                 | シャットダウンコマンドをクライアントコンピュータに送信        |
| 16  | Send UPS shutdown command to UPS      | 6                 | UPS に UPS 停止コマンドを送信                |
| 17  | Send shutdown cancel to clients       | 6                 | 障害イベント復旧により、シャットダウンキャンセルをクライアントに送信 |
| 18  | Send UPS output on command to UPS     | 6                 | UPS に UPS 停止キャンセルを送信               |
| 19  | UPS communication lost                | 4                 | UPS と通信不可                          |
| 20  | UPS communication restored            | 6                 | UPS と通信復旧                          |
| 21  | Time changed by user                  | 6                 | ユーザが設定ページで時間を設定                    |
| 22  | Time changed by server                | 6                 | NTP サーバと同期により時間設定                  |
| 23  | Time changed by RTC                   | 6                 | リスタート時に RTC より時間を設定                |
| 24  | Can't connect to mail server          | 4                 | Mail 送信時、メールサーバに接続不可               |
| 25  | Incorrect Mail receiver               | 4                 | Mail 送信先アドレス不正                     |
| 26  | Incorrect Mail server name/IP address | 4                 | Mail サーバ名または IP アドレスの不正            |
| 27  | Mail send error/unknown error         | 4                 | メール送信失敗                            |
| 28  | Mail sent                             | 6                 | メール送信                              |

### Note : Severity level

| Numerical Code | Severity                                 |
|----------------|--|
| 0              | Emergency: system is unusable            |
| 1              | Alert: action must be taken immediately  |
| 2              | Critical: critical conditions            |
| 3              | Error: error conditions                  |
| 4              | Warning: warning conditions              |
| 5              | Notice: normal but significant condition |
| 6              | Informational: informational messages    |
| 7              | Debug: debug-level messages              |